





SECURITY SAFE BOX
INSTRUCTION MANUAL

Component Description



Package List

Item	Security Safe Box	Emergency Keys	Mounting Screws	User Manual	Mat
Picture					
Quantity	1	2	4	1	1

Basic Operating Instructions

Dear Customer:

Thank you for choosing our products! You have taken an important step in organizing and protecting your valuables. Every series of our safes is professionally made and designed to provide safety. Please take the time to read the user manual and familiarize yourself with the proper operating procedures of your new safe.

1.Initial Use

① Find the emergency keys in the accessories box.

② Remove the external battery case cover.

③ Insert the emergency key, press gently and turn it counterclockwise, then twist the knob clockwise to open the safe.

Caution: After completing the operation, pull out the emergency key and store it in a safe place.

2.Insert the Batteries

① Choose to insert 4 x 1.5V AA batteries into either the internal or external battery case, depending on your personal needs.

② Note that if the red light is on it indicates low battery and you need to replace it with a new one.

Caution: When replacing batteries, align them according to the "+" and "-" signs. If the batteries are depleted for longer than 30 minutes, the passcode will be reset.

3.Automatically Locked


① Three consecutive incorrect passcode attempts will trigger a 20-second warning beep.

② Another three consecutive incorrect attempts will extend the warning beep to 5 minutes.

Caution: During the beep alarm, the keypad will be locked. Remove the batteries to stop the alarm sound.

How to Open The Safe

1. Using the Emergency Key



① ② ③


① Remove the key cover.

② Insert the key and turn counterclockwise.

③ Turn the knob clockwise to open the safe.

Tip: Do not store the emergency keys inside the safe.

2. Using the Passcode



① You can install the battery in the external battery case or the internal battery case.

② Enter correct passcode and press "#" to confirm.

③ Turn the knob clockwise to open the safe.

Tip: The default passcode is "**159**".

How to Set Your Passcode

① With the door opened, press the Reset Button behind the door, the buzzer will beep once with flashed yellow indicator light.


② Input your personal passcode within 3~8 digits and press “#” button to confirm, the buzzer will beep once with flashed yellow indicator light.

Caution: If the yellow indicator light is off, indicates that the passcode has been set successfully.

Mute Function

① To Enable Mute Mode: Long press the number "1" key for 5-8 seconds.
② To Disable Mute Mode: Long press the number "1" key again for 5-8 seconds.

Steps for Mounting



① Drill holes of the appropriate size for the anchors.

② Carefully press the anchor into the holes.

③ Mount the safe by running screws from inside of the safe and securing to anchors. Ensure the safe is mounted securely.

